XL35 Mini Par Light

Instruction Manual

Thank you for choosing the LED Par light, which is a light and portable multi-modal stage light . Whenever you go dancing or to a show or gather in a home party, it can fuel your passion and create the best visual atmosphere .The manual describes how to use it and the safety issues. Please read it carefully and keep it as your reference.

A. Package includes :

1 *Par Light , 1 * Bracket ,1 * Accessory Kit (2 knobs, 2 pads), 1 *User manual.

B. Technical specifications:

1. Operating Voltage: AC110-220V ,50-60HZ.
2. Power: 10W.
3. LED lifespan: 50,000 hours.
4. Light bead: 86pcs ¢ 5MM LED light beads (Red : 44pcs , Green : 21pcs , Blue : 21pcs) .
5. Operating modes: single color switch mode, Automatic running, DMX, Sound Active, Master/Slave
7. Work environment: indoors.
8. Work temperature: -20 C °--40C °.
9 .Package size :. 140 * 140 * 140MM.

C. The code sets and description:

1. Single color switch Mode

■	■	■	■	■	■	□	□	□	□	ON
1	2	3	4	5	6	7	8	9	10	OFF

When you push the **"1"**or **"2"**button at ON ,the **Red** LED will lights up. And the **"2"** is brighter than **"1".** Similarly, **"3" "4**" is correspond to **Green** light, **"5" "6**"is correspond to **Blue** light. And the Dual is always bright than Singular.

2.Sound-active Mode

□	□	□	□	□	□	□	■	□	□	ON
1	2	3	4	5	6	7	8	9	10	OFF

When you push the **"8"** button at ON , the stage light is in sound active mode.

3. Automatic running Mode

□	□	□	□	□	□	□	□	■	□	ON
1	2	3	4	5	6	7	8	9	10	OFF

When the button "9"is in the "ON" state, the par light enters Automatic running Mode, Color of output will gradual change.

Gradient speed adjust method:

■	■	■	■	■	■	■	■	■	□	ON
1	2	3	4	5	6	7	8	9	10	OFF

When it is running you can push the "1-8" button at ON, the more button you push , the more slower of the color changing speed.

4. DMX 512 Mode

■	□	□	□	□	□	□	□	□	■	ON
1	2	3	4	5	6	7	8	9	10	OFF

When the button"1"and"10" in the "ON" state, you can use the DMX512 function.

5. Master-slave Mode

(1). Master Mode



(2).Slave Mode



Master-slave mode setting: When the button "10" is set to "OFF" state, and all the rest can set to the “OFF” or “ON” state, this par light is the Master machine.

When the button "10"and”1” is set to "ON" state, and all the rest is set to the “OFF” state, this par light is the attached machine.

As you using the master and slave mode, you must disconnect the other DMX512 signal source.

D．DMX512　Channels Mode

NO	Digital Converter	Description
CH1	16-79 80-160 161-255	Strobe Flash of white light(slow to fast) single color light
CH2	1-255	Main switch of brightness(dimmer to bright)
CH3	1-255	Red led dimmer
CH4	1-255	Green led dimmer
CH5	1-255	Blue led dimmer

E．NOTE:

1. Before the product be energized, please make sure that there is enough space and the Circuit, Operating voltage meets the product requirements, Otherwise stop using it.

2. According to the individuals needs and case , set the different Mode by pressing the code button. Please notice that the function of the product can only be done on a single mode.

3.When using DMX512 Mode, you must ensure that the signal transmission line is a normal conductive, In order to ensure good contact with each product.

4. We recommend that unplug the power wire at once when the light can’t work normally or in the abnormal power supply. Please turn to the local maintenance department rather than dismantle it by yourself.

5. Be careful of the cover glass. This product is not available when the glass is broken. Please promptly clean up the debris of glass to prevent injuries.

F．Feedback:

You satisfaction is the motivation for the TSSS team to keep forward.If you are satisfied with our product, we will greatly appreciate it if you give us a five-star feedback and leave positive comments on your experience with us!If you have any questions or problems, please free to contact us. We take care of every feedback from you，and strive to perfect our product all the times.